

### **TOP AND CONSOLE PARTS**


For Models: LGR6646BW2, LGR6646BN2 (White) (Almond)

	(111110)							
Illus.	Part		lllus.	Part		lllus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
	110.	DECORNI HOR	<del>-110.</del>	110.	BEGGIAII TIGIT	<del>-110.</del>	110.	DECORNI MON
1	3397545	Panel, Rear	12	339229	Hinge, R.H.	30	693995	Screw (6)
		Console		339230	Hinge, L.H.	39	3398094	Switch,
2	688805	Clip	13	688983	Screw, 8-18 x 5/8			Push-To-Start
2 3	3396029		14	3353145	Screw, Console	48	3396145	Timer Knob
J	0000020	Assembly	15	3390646	Screw, 8-18 x 5/16		0000110	Assembly
4		Cap, End (L.H.)	16		Тор	49	3401144	Connector,
	3358531	White		3396022	White			(PTS Relay)
	3358532	Almond		3396023	Almond	53	3396293	Bracket, Control
6			17	694419	Buzzer, Mini	54	0000200	Panel, Control
6	689180	1 /	18	94614	Terminal, Female	] 54	3397210	White
/		Cap, End (R.H.)	19	3358431	Knob, Cycle			
	3358516		19	3330431			3397211	Almond
	3358517	Almond			Selection	72	690853	Wire, Ground
8	357213	Nut, Push-In (2)	20	3397269	Connector, Timer	75	717252	Receptacle,
9	3395683	, , ,	21	3398137	Timer Assembly,	79	3396013	Switch, Cycle
-		(Motor)			60 Hz.			Selection
10	349639	` ,	23	3401626	Harness, Wiring	81	3396160	Knob,
11	043003	,	24	3394427	Clip, Harness	l °'	0000100	Push-To-Start
1.1	000450	Cover, Lint Screen		000	Cp.,a			Fusii-10-3iaii
	688150							
	689310	Almond	I			l		

## LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	
LITERATURE PARTS			OPTIONAL PARTS NOT INCLUDED						
	LIT3401083 Guide, Use & Care LIT3395332 Instructions,		PAINT, TOUCH-UP (1/2oz.)			PAINT, BULK (1 qt.)			
	LIT3401723	Installation		72017 72107		799344 978883		( /	
		- 1-1g-1-11	PAIN	IT, PRESS	SURIZED SPRAY	Following May Be Purchase			
			350930 350956 350938		6 Almond	1	D-IT-YOU PAIR MA	NUALS	

## **CABINET PARTS**




CABINET PARTS
For Models: LGR6646BW2, LGR6646BN2
(White) (Almond)

Illus.	Part		Illus.	Part		l Illus.	Part	
		DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
No.	NO.	DESCRIPTION	<u>NO.</u>	NO.	DESCRIPTION	<u>NO.</u>	NO.	DESCRIPTION
1	697776	Screw, 10-16 x 1/2	23	685203	Clip, Felt Pad	63	660658	Clamp, Motor (2)
		(Ground)	24	690081				343481 (Alt.)
2	343641	Screw, 10-16 x 1/2			Assembly			685441 (Alt.)
3	693995	•	26	3388229		67	3401771	Burner Assembly
		Washer Head			Panel (2)			60 Hz. (Alternate)
4	687905		31	98997				(Refer To Pages 5
	687906		32	694091	Screw			and 6
5		Cover, Block	33	696144	Strike, Door			For Further
6	342043	Screw,	35	695954	Door, Rear			Burner Breakdown)
		10-32 x 1/2	36		Door, Front	68	341029	
7		Panel, Rear		348728	White	69	694572	
8	3357011			689330	Almond			(Type 1, 2 &
		10-16 x 1/2	37		Handle, Door			3 To Type 4)
9	691581			690270	White	85	3401775	
10	347207	,		690271	Almond			60 Hz.
11	98129		38	349464	Seal & Bearing			(Complete)
		6-20 x 1-3/8 (2)			Assembly	86	660991	Ignitor
12	237979	Spring, Door (2)	42	3390733	Seal, Door			686590 (Alt.)
13	337189		45	344020	Cord, Power	87	3393909	Screw & Washer
14	238614	Bumper	48	297092	Clip, Hinge (2)	88	694539	Coil, 60 Hz.
16	3392100	Foot, Dryer	49		Panel, Toe			(Split)
		(Plastic)		692427				(3 Terminal)
	279810	Foot-Optional		692428	Almond			(Pilot Position)
		(Extended Length)	51	238088		89	694540	Coil, 60 Hz.
		(Package Of 2)	53	691366				(2 Terminal)
		(Not Included.)	56	660996				(Main)
18		Cabinet	57	348780		90	694421	Screw, Bracket
	3399585	White	58	172455				Mounting
	3399586	Almond			5/16-18 x 3/4			(8-32 X 1/2) 2
		(Includes Illus.	59	3401143	Pulley, 60 Hz.	91	694538	
		Nos. 5, 7, 16,	62	3395652	Motor Assembly	93	694424	
		And 57.)	"-	000000	60 Hz.	94	694423	Screw, Regulator
19	98234				(Pulley Not			Adjustment
20	690363				Included With	95	694422	Spring, Regulator
-		Top (2)			Motor)	97	239822	
21		Upper Front					_	J' 1
		Panel						
	338012							

## 3401771 BURNER ASSEMBLY

For Models: LGR6646BW2, LGR6646BN2 (White) (Almond)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



## 3401771 BURNER ASSEMBLY

For Models: LGR6646BW2, LGR6646BN2 (White) (Almond)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus.	Part	
No.	No.	DESCRIPTION
1	3401771	Burner Assembly 60 Hz. (Type 1, 2 & 3)
2	688617	(White Rodgers)
2	694298	Tube, Burner Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer
3	3333303	(8–32 x 5/8)
6	343641	Screw 10_16 v 1/2
7	693986	Screw, 10–16 x 1/2 Base, Burner
8	3387057	Screw,
O	0007007	8–18 x 3/8 (2)
9		Orifice, Burner
-	234826	Type 1
	15775	Type 2
	15419	Type 2 Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw,
		8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz.
		(2 Terminal)
	00.4500	(Main)
14	694539	Coil, 60 Hz.
		(Split)
		(3 Terminal)
15	694424	(Pilot Position) Leak Limiter
16	694423	Screw, Regulator
10	094423	Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	345062	Valve & Union,
	0.000_	Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe


Following Parts Not Illustrated

694572 Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.

BA-128

# **BULKHEAD PARTS**

For Models: LGR6646BW2, LGR6646BN2 (White) (Almond)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3396352	Lint Chute	13	3400800	Screw, 8-18 x 3/4	43	3399507	Shaft, R.H.
		Assembly	14	685458	Box, Heater	44	3397588	Roller, Support
2	343641	Screw, 10-16 x 1/2	15	3388697	Thermostat, 205 °F	46	348197	Washer, Support
5	90767	Screw, 8A x 3/8			(96 °C)	47	3359452	Nut, 3/8–16
6	3392519	Fuse, Thermal	16	348484	Support, Heater	48	3399464	Bulkhead
7	347139	Seal, Lint			Box	49	338906	Sensor, Radiant
		Chute	17	348516	Collar, Funnel	62	3394509	Ring, Bearing
8	3387139	Thermostat.	18	347389	Funnel, Burner	63	97787	Screw, 11–16 x 7/8
		Internal Bias	19	339554	Screw	66	3397509	Seal, Rear Drum
9	3388703	Washer, Support	20	3392123	Seal, Blower	67	3396778	Drum Assembly
10	694089	Wheel, Blower	23	90767	Screw, 8A x 3/8	68	342847	Baffle, Drum
11	695081	Housing, Blower	24	696302	Shield, Exhaust	69	3394133	Bracket, Support
12	3398161	Clip	41	690997	Ring, Tri	70	90296	Clip
	2300.01	÷t	42	3399506	Shaft, L.H.	73	3398160	Seal